

# A QUICK LOOK AT POP-UP DISPLAYS

## HERE'S HOW WE DID IT!



*Product expertise at your fingertips.*





**DIFFICULTY LEVEL:  
INTERMEDIATE**

**APPROXIMATE SIZE:  
10' WIDE X 8' HIGH**

**SUGGESTED PROPS:  
PICTURE FRAMES  
CAPS · CATALOGS**



## SUPPLIES

- 2 CASES OF DARK LAMINATE FLOORING (20PCS)
- SET OF 2 OR 3 PRE-AGED NESTING TABLES
- 3 FAUX STONE 4'X 8' PANELS 4X8
- 4 WOOD 2'X 4'X 8' BEAMS
- 6 WOOD 2'X 4'X 4' BEAMS
- 2 WOOD 2'X 4'X 3' BEAMS
- 4 WOOD 2'X 4'X 4' BEAMS
- 5 12"X 18" BASKETS
- 3 8"X 10" BASKETS
- FELT FABRIC
- 2 SAND BAGS
- 3 18'X 22' BRANDED SIGNS
- 1 1"X 8' WOOD TRIM
- 12 CORNER FRAMING BRACKETS
- SCREWDRIVER
- IMPACT DRILL
- AMERICAN WALNUT STAIN
- PAINTER RAGS
- PICTURE-FRAMING WIRING
- 1 12"X 1"X 36" WOOD BOARD
- KONA STAIN
- 120 GRIT AND 80 GRIT SANDPAPER
- 1 BOX OF 3-1/2" SCREWS
- 3/4" INDUSTRIAL PIPING
  - 8 FLANGES
  - 5 12" PIPES
  - 4 8" PIPES
  - 1 36" PIPE
  - 3 90-DEGREE PIPES
  - 3 PIPE T-BARS
  - 1 3" PIPE
  - 2 1" PIPES
  - 1 PIPE SPOUT
  - 1 PRESSURE GAUGE
  - 5 PIPE END CAPS

## HOW TO CREATE THIS DISPLAY

- 1 STAIN THE NESTING TABLES WITH THE KONA STAIN.
- 2 MAKE THE FRAME FOR THE BACKDROP. USE 4 PIECES OF 2'X 4'X 8' AS THE SIDE PIECES OF THE WALL AND USE 6 PIECES OF 2'X 4'X 8' FOR THE TOP AND BOTTOM PIECES. SECURE THE PIECES TOGETHER WITH 3-1/2" SCREWS.
- 3 SECURE THE 3 PIECES OF FAUX STONE WALL PANELS TO THE FRAME. USE 6 SCREWS FOR EACH PANEL, 1 IN EACH CORNER AND 2 ON EACH SIDE.
- 4 AGE THE FAUX STONE WALL WITH THE AMERICAN WALNUT STAIN AND A PAINTER'S RAG. GO OVER ALL THE WALLS LIGHTLY WITH THE STAIN. WITH EACH PASS CREATE DIFFERENT LAYERS OF STAIN SO SOME AREAS ARE DARKER THAN OTHERS.
- 5 CREATE LEG SUPPORTS WITH THE 2'X 4'X 3' AND 2'X 4'X 4' DRILLED TO THE SIDES OF THE WALLS.
- 6 USE SAND BAGS SET ON THE LEG SUPPORTS TO WEIGH DOWN THE DISPLAY.
- 7 MAKE THE HANG BAR ON THE FAR RIGHT PANEL. CONNECT A 36" PIPE TO 2 12" PIPES ON EITHER SIDE. SCREW FLANGES TO THE WALL AND SECURE THE HANG BAR TO IT.
- 8 MAKE THE SHELF ON THE RIGHT PANEL. SAND AND STAIN THE 12"X 1"X 36" PANEL WITH KONA. SCREW IN TWO FLANGES AND ATTACH 2 PIECES OF 12" PIPE TO THEM. SET THE SHELF ON THE PIPES.
- 9 SCREW THE PRESSURE GAUGE AND SPOUT INTO A 1" PLUMBER PIPE. THEN SECURE IT TO EITHER A T-BAR OR 90-DEGREE PIECE THAT'S CONNECTED TO THE 12" PIPED HANG BAR.
- 10 FRAME THE BRANDED SANMAR SIGNS WITH THE TRIM SIDING. CUT THE TRIM TO THE DESIRED SIZE. USE A CHOP SAW AT A 45-DEGREE ANGLE FOR THE CORNERS. SECURE THE PIECES TOGETHER WITH L-BRACKETS. STAIN THE FRAMES WITH KONA. ALLOW THEM TIME TO DRY COMPLETELY.
- 11 HANG THE FRAMES ON THE WALL. ATTACH PICTURE-FRAMING WIRING TO THE BACK OF EACH FRAME. DRILL A SCREW INTO THE WALL FOR THE FRAME TO HANG ON.
- 12 CONNECT THE BASKETS TOGETHER TO MAKE A SINGLE UNIT.
- 13 ACCESSORIZE WITH APPAREL AND PROPS AS DESIRED.



## TIPS

- ✓ USE KONA STAIN BECAUSE IT IS DARKER AND WHEN SANDED CREATES A MORE EXTREME, AGED LOOK
- ✓ REINFORCE ALL OF THE PLACES WHERE PIPING IS SECURED TO THE WALL WITH A 2'X4' TO CREATE EXTRA SUPPORT. WITHOUT THE EXTRA SUPPORT, THE WEIGHT OF THE PRODUCT WILL BREAK THE WALL.
- ✓ SANMAR SELLS BRANDED 18'X22' SIGNS FOR USE IN YOUR DISPLAY
- ✓ USE VELCRO ON THE CORNERS OF THE PICTURE FRAMES TO MAKE THEM EXTRA SECURE ON THE WALL PANELS