

**DIST
RICT®**



**WE'VE GOT
INSPIRATIONAL
MARKETING
DOWN
TO A TEE!**

SANMAR



FRONT VIEW



BACK VIEW

WANT TO TAKE YOUR MOBILE DISPLAY TO THE NEXT LEVEL?

LET US SHOW YOU HOW!

SUPPLIES

- 3 IKEA EKET CABINETS WITH DOOR AND 2 SHELVES, WHITE
- 2 4" GALVANIZED CORNER BRACE (4-PACK)
- 4 RUBBER CASTER WHEELS
- 1 PACK OF EVERBIL 3/4" SHEET METAL SCREWS
- 4 IKEA OLOV ADJUSTABLE TABLE LEGS, GREY
- 1 IKEA GRUNDTAL TOWEL HANGER/SHELF, STAINLESS STEEL
- 1 3 1/2" X 96" X 3/4" WHITE PRIMED FINGER-JOINTED MOULDING BOARD
- HAND SAW
- 2 14" SOFT CLOSE BALL BEARING DRAWER SLIDES
- 2 12" X 48" WHITE SHELVES
- 4 CERAMIC INSERT DRESSER KNOBS, CHROME OR WHITE
- 1 IKEA FIXA SCREWDRIVER/DRILL
- 4 3/4" FLAT-HEAD MACHINE SCREWS WITH BOLT NUT
- 4 1 FT. ZINC-PLATED CHAIN
- 9 LED PORTABLE TASK LIGHTS
- CLOTHING HANGERS
- ASSORTED APPAREL

HOW TO CREATE THIS DISPLAY

- 1** BUILD THE THREE EKET CABINETS USING THE ACCOMPANIED INSTRUCTIONS.
- 2** USE THE GALVANIZED CORNER BRACES TO SECURE THE SHELVES ON THE INSIDE OF EACH EKET CABINETS.
- 3** DRILL THE FOUR RUBBER CASTER WHEELS TO THE BOTTOM OF ONE EKET CABINET.
- 4** STACK A SECOND EKET CABINET ON TOP OF THE FIRST ONE, SO THE DOORS SWING OPEN HORIZONTALLY FROM TOP TO BOTTOM.
- 5** DRILL THE EKET CABINETS TOGETHER FROM THE BACK USING SCREWS.
- 6** DRILL THE 4 OLOV LEGS TO EACH CORNER OF THE TOP EKET CABINET.
- 7** ADJUST THE LEGS SO THAT THEY ARE ALL AN EVEN HEIGHT, ABOUT 2.5' HIGH.
- 9** DRILL THE EKET CABINET ON TOP OF THE 4 OLOV LEGS, USING THE 4 WASHERS PROVIDED IN THE IKEA BOXES.
- 10** MARK WHERE YOU WANT TO HANG THE GRUNDTAL TOWEL HANGER ON THE BOTTOM OF THE TOP EKET CABINET. ENSURE IT WILL HANG IN THE CENTER-REAR OF THE DISPLAY.
- 11** PRE-DRILL A HOLE WITH A SMALL DRILL BIT IN THE MARKED LOCATIONS.
- 12** ONCE THE HOLES HAVE BEEN FORMED, ATTACH THE GRUNDTAL WITH THE MACHINE SCREWS AND SECURE WITH THE BOLT NUT ON THE INSIDE OF THE EKET CABINET.
- 13** WITH THE HAND SAW, CUT THE WHITE MOULDING BOARD INTO TWO 41.5" PIECES.
- 14** DRILL ONE OF THE 41.5" MOULDING BOARDS TO THE BACK OF THE UPPER EKET CABINET, ALIGNED ALONG THE BOTTOM EDGE.
- 15** DRILL THE SECOND 41.5" MOULDING BOARD TO THE BACK OF THE MIDDLE EKET CABINET, ALIGNED ALONG THE TOP EDGE.
- 16** SECURE A BALL BEARING DRAWER SLIDE TO THE TOP AND BOTTOM OF THE 12" X 48" WHITE SHELF WITH SCREWS.
- 17** REPEAT ON THE SECOND 12" X 48" WHITE SHELF.
- 18** SECURE THE OTHER SIDE OF THE BALL BEARING DRAWER SLIDE TO THE MOULDING BOARD WITH SCREWS SO THE SHELVES HANG VERTICAL ALONG EACH SIDE OF THE DISPLAY.
- 19** MARK WHERE YOU WANT THE CERAMIC DRESSER KNOTS ON EACH SHELF.
- 20** PRE-DRILL A HOLE WITH A SMALL DRILL BIT WHERE YOU HAVE MARKED.
- 21** ONCE THE HOLES ARE FORMED, ATTACH THE DRESSER KNOBS WITH THE INCLUDED BOLTS.
- 22** WITH THE DRILL, ATTACH THE 1FT. CHAINS TO EACH END OF THE OPEN CABINETS SO THEY PROP OPEN THE DOORS.
- 23** ATTACH MAGNETIC TASK LIGHTS TO THE TOP CENTER OF EACH DISPLAY SECTION.
- 24** ARRANGE APPAREL ON DISPLAY USING HANGERS AND ACCESSORIES.

