



# A QUICK LOOK AT MOBILE DISPLAYS

HERE'S HOW  
WE DID IT!



FRONT VIEW



BACK VIEW

**SANMAR U**

*Product expertise at your fingertips.*

**DIFFICULTY  
LEVEL: EXPERT**

**APPROXIMATE SIZE:  
7' WIDE X 8' HIGH**

**SUGGESTED PROPS:  
ASSORTED APPAREL  
CAPS · BOOKS · PENS**

## SUPPLIES

- 3 IKEA EKET CABINETS WITH DOOR AND 2 SHELVES, WHITE
- 2 4" GALVANIZED CORNER BRACE (4-PACK)
- 4 RUBBER CASTER WHEELS
- 1 PACK OF EVERBIL  $\frac{3}{4}$ " SHEET METAL SCREWS
- 4 IKEA OLOV ADJUSTABLE TABLE LEGS, GREY
- 1 IKEA GRUNDTAL TOWEL HANGER/SHELF, STAINLESS STEEL
- 1  $3\frac{1}{2}$ " X 96" X  $\frac{3}{4}$ " WHITE PRIMED FINGER-JOINTED MOULDING BOARD
- HAND SAW
- 2 14" SOFT CLOSE BALL BEARING DRAWER SLIDES
- 2 12" X 48" WHITE SHELVES
- 4 CERAMIC INSERT DRESSER KNOBS, CHROME OR WHITE
- 1 IKEA FIXA SCREWDRIVER/DRILL
- 4  $\frac{3}{4}$ " FLAT-HEAD MACHINE SCREWS WITH BOLT NUT
- 4 1 FT. ZINC-PLATED CHAIN
- 9 LED PORTABLE TASK LIGHTS
- CLOTHING HANGERS
- ASSORTED APPAREL

## HOW TO CREATE THIS DISPLAY

- 1 BUILD THE THREE EKET CABINETS USING THE ACCOMPANIED INSTRUCTIONS.
- 2 USE THE GALVANIZED CORNER BRACES TO SECURE THE SHELVES ON THE INSIDE OF EACH EKET CABINETS.
- 3 DRILL THE FOUR RUBBER CASTER WHEELS TO THE BOTTOM OF ONE EKET CABINET.
- 4 STACK A SECOND EKET CABINET ON TOP OF THE FIRST ONE, SO THE DOORS SWING OPEN HORIZONTALLY FROM TOP TO BOTTOM.
- 5 DRILL THE EKET CABINETS TOGETHER FROM THE BACK USING SCREWS.
- 6 DRILL THE 4 OLOV LEGS TO EACH CORNER OF THE TOP EKET CABINET.
- 7 ADJUST THE LEGS SO THAT THEY ARE ALL AN EVEN HEIGHT, ABOUT 2.5' HIGH.
- 8 DRILL THE EKET CABINET ON TOP OF THE 4 OLOV LEGS, USING THE 4 WASHERS PROVIDED IN THE IKEA BOXES.
- 9 MARK WHERE YOU WANT TO HANG THE GRUNDTAL TOWEL HANGER ON THE BOTTOM OF THE TOP EKET CABINET. ENSURE IT WILL HANG IN THE CENTER-REAR OF THE DISPLAY.
- 10 PRE-DRILL A HOLE WITH A SMALL DRILL BIT IN THE MARKED LOCATIONS.
- 11 ONCE THE HOLES HAVE BEEN FORMED, ATTACH THE GRUNDTAL WITH THE MACHINE SCREWS AND SECURE WITH THE BOLT NUT ON THE INSIDE OF THE EKET CABINET.
- 12 WITH THE HAND SAW, CUT THE WHITE MOULDING BOARD INTO TWO 41.5" PIECES.
- 13 DRILL ONE OF THE 41.5" MOULDING BOARDS TO THE BACK OF THE UPPER EKET CABINET, ALIGNED ALONG THE BOTTOM EDGE.
- 14 DRILL THE SECOND 41.5" MOULDING BOARD TO THE BACK OF THE MIDDLE EKET CABINET, ALIGNED ALONG THE TOP EDGE.
- 15 SECURE A BALL BEARING DRAWER SLIDE TO THE TOP AND BOTTOM OF THE 12" X 48" WHITE SHELF WITH SCREWS.
- 16 REPEAT ON THE SECOND 12" X 48" WHITE SHELF.
- 17 SECURE THE OTHER SIDE OF THE BALL BEARING DRAWER SLIDE TO THE MOULDING BOARD WITH SCREWS SO THE SHELVES HANG VERTICAL ALONG EACH SIDE OF THE DISPLAY.
- 18 MARK WHERE YOU WANT THE CERAMIC DRESSER KNOTS ON EACH SHELF.
- 19 PRE-DRILL A HOLE WITH A SMALL DRILL BIT WHERE YOU HAVE MARKED.
- 20 ONCE THE HOLES ARE FORMED, ATTACH THE DRESSER KNOBS WITH THE INCLUDED BOLTS.
- 21 WITH THE DRILL, ATTACH THE 1FT. CHAINS TO EACH END OF THE OPEN CABINETS SO THEY PROP OPEN THE DOORS.
- 22 ATTACH MAGNETIC TASK LIGHTS TO THE TOP CENTER OF EACH DISPLAY SECTION.
- 23 ARRANGE APPAREL ON DISPLAY USING HANGERS AND ACCESSORIES.

